

2.0 RELIANCE ETES Parts

To order parts, call ADB SAFEGATE Customer Service or your local representative. Use this four-column parts list, and the accompanying illustration, to describe and locate parts correctly.

Figure 2: RELIANCE ETES Assembly




Figure 3: L-861T ETES Fixture (part 1 of 2)




Figure 4: L-861T ETES Fixture (part 2 of 2)

